

Introduction

The Copper 3-Arm Mechanical Wiper P/N: 2300/2360-450 reduces bio-fouling during extended deployments.

Features

- Helps maintain consistent readings by reducing bio-fouling.
- Copper deters settling and growth of organisms on or near the sensors.

Replaceable Components

- Brushes:
C3 P/N: 2300-460,
C6P and PhytoFind P/N: 2200-460
- Spacers:
C3 P/N: 2300-462
C6P and PhytoFind P/N: 2360-462
- Copper Wiper Arm Kit:
C3 P/N: 2300-459
C6P and PhytoFind P/N: 2360-459




Installation

- 1) Connect the C3, C6P to a computer that has C-Soft software; or connect the PhytoFind to a computer that has the PhytoFind software. Supply power.
- 2) Start the software.
- 3) Click on the Log Data tab in C-Soft or Log Setup tab in the PhytoFind software.
- 4) Click the Test Wiper button to bring the motor shaft to its home position.
- 5) Install O-ring into motor shaft groove.


Note: Do not lubricate O-ring

- 6) Slide the wiper assembly onto the motor shaft with brushes facing towards the optical head and position the brushes between two sensors.



- 7) Hand-tighten nut to secure wiper assembly.


Note: Do not use any tools to tighten the tightening nut.



- 8) Click Test Wiper.
- 9) If the wiper does not come to rest in the desired position, unscrew the tightening nut, remove the wiper assembly, and repeat steps 6-8.

Mechanical Wiper Removal


- 1) Loosen and remove the nut securing the wiper assembly.



- 2) Slide the wiper assembly off the motor shaft.


Wiper Replacement Installation

- 1) Connect the C3, C6P to a computer that has C-Soft software; or connect the PhytoFind to a computer that has the PhytoFind software. Supply power.
- 2) Start the software.
- 3) Click on the Log Data tab in C-Soft or Log Setup tab in the PhytoFind software.
- 4) Click the Test Wiper button to bring the motor shaft to its home position.
- 5) Remove the old O-ring and install the new O-ring into motor shaft groove. **Note: Do not lubricate O-ring**
- 6) Slide the new wiper assembly onto the motor shaft with brushes facing towards the optical head and position the brushes between two sensors.




- 7) Hand-tighten nut to secure wiper assembly.

Note: do not use any tools to tighten the tightening nut.



- 8) Click Test Wiper.
- 9) If the wiper does not come to rest in the desired position between two optical heads, unscrew the tightening nut, remove the wiper assembly, and repeat steps 6-8.

Replacement Brush Installation



The wiper brushes should be replaced when they are no longer effectively wiping the sensor heads – this will be noticeable if deposits begin to build up on the optical face.

- 1) Using the Allen Wrench provided, loosen the arm locking screw. **Note: If this is not provided or lost, it is a 1mm diameter Allen Key.** Loosen the arm locking screws on the wiper brush arm you wish to replace and pull out the brush arm. Refer to figure above for wiper assembly and components. **Caution: The screws are very small; loosen the screw just enough to pull out the brush arm, do not fully remove the screw.**
- 2) Pull out the brush arm with brush.
- 3) Slide the brush towards the open end of the brush arm to remove the spacer and the brush.
- 4) Slide in a new brush. Slide in the spacer. **Note: do not push the brush or spacer in too far or it may cause the brush bristles to bend inwards when the wiper is replaced onto the instrument.**
- 5) Position the brush arm onto the wiper assembly and tighten the arm locking screw.